s.QUAD Accessories

SWISSPHONE

Charger s.QUAD

- Quick charger with a controlled charging current
- LED indication for operation- and charging mode
- Potential relay contact with programmable switching time
- 6-PIN socket for easy connection of external devices (relay contact and 5 V DC source)
- BNC connector for external antenna






Charger s.QUAD with Lamp

- Quick charger with a controlled charging current
- LED indication for operation- and charging mode
- Automatically turns on the LED light on reception of an alert with programmable switching time
- LED can be turned on or off manually
- BNC connector for external antenna

Multi Charger s.QUAD


- Multiple charger with individually controlled charging current
- 4 or optionally 8 charging slots
- LED indication for operation and charging mode (each slot)
- Optional LAN connectivity for absence management



s.QUAD Accessories

Programming Kit s.QUAD

- Connect via USB port
- Incl. programming software and programming manual





Drawstring / Lanyard, Clip

Drawstring / lanyard

- Length 36 cm / 14.17 inches
- Loss protection for the s.QUAD

Clip

Black belt clip

Clip holder

• Plastic, black (display facing outwards)

Leather Cases

Models

- Flip down case
- Leather case





Swissphone Wireless AG Fälmisstrasse 21 CH-8833 Samstagern Tel +41 44 786 77 70 Fax +41 44 786 77 71 E-Mail info@swissphone.com swissphone.com Swissphone LLC 561 Garden Drive, Unit D Windsor, CO 80550 Phone +1 800 596 1914 Fax +1 970 460 3014 E-mail info.usa@swissphone.com swissphone.com